



Earshot User Guide

Revision H
Version 0
April 2025
Document DOC-VS-EAR-UG-H-0

Advanced Simulation Technology inc.
500A Huntmar Park Drive • Herndon, Virginia 20170 USA
(703) 471-2104 • asti-usa.com

Product Name: Voisus

Earshot User Guide

© Copyright ASTi 2025

Restricted rights: copy and use of this document are subject to terms provided in ASTi's Software License Agreement (www.asti-usa.com/license.html).

ASTi
500A Huntmar Park Drive
Herndon, Virginia 20170 USA

Red Hat Enterprise Linux (RHEL) Subscriptions

ASTi is an official Red Hat Embedded Partner. ASTi-provided products based on RHEL include Red Hat software integrated with ASTi's installation. ASTi includes a Red Hat subscription with every purchase of our Software and Information Assurance (SW/IA) maintenance products. Systems with active maintenance receive Red Hat software updates and support directly from ASTi.

Export Restriction

Countries other than the United States may restrict the import, use, or export of software that contains encryption technology. By installing this software, you agree that you shall be solely responsible for compliance with any such import, use, or export restrictions. For full details on Red Hat export restrictions, go to the following:

www.redhat.com/en/about/export-control-product-matrix

Revision history

Date	Revision	Version	Comments
02/21/2017	B	0	Updated "Viewpoints," "Earshot Statistics," "Environmental Sounds," and "Earshot Sound Files" sections. Added new "MetaVR Terrain Data," "Custom Mappings," and "VR-Forces Weather" sections. Edited content for grammar and accuracy.
07/13/2017	C	0	Updated screenshots in "Custom Mappings" and split content into "Add a custom mapping" section. Added new "Define custom fire and detonation overrides" and "Export custom mappings to spreadsheet" sections.
03/20/2019	D	0	(7.2.0) Updated Speakers table in "Viewpoints" and documented FIPS warning message in "MetaVR™ Terrain Data." Removed broken hyperlink in "Add a custom mapping."
6/25/2019	E	0	(7.3.0) Added "VoisNet Synchronization."
12/6/2019	E	1	Corrected support email address in "MetaVR™ Terrain Data."
9/18/2020	F	0	Updated screenshots in the Voisus web interface.
10/26/2020	F	1	Updated the restricted rights statement in the front matter.
8/10/2021	G	0	Updated "Enable VoisNet Synchronization on the Voisus server" to include the new Features page. Updated all screenshots of table header styles.
3/8/2023	G	1	Added Red Hat Enterprise Linux subscription and export statement to front matter.
4/25/2025	H	0	(8.7.0) Updated the Features page screenshot in "Enable VoisNet Synchronization on the Voisus server." Documented Transmit Audio on Radio in "Broadcast audio on a radio."

Contents

1.0 Introduction	1
2.0 Viewpoints	2
2.1 Broadcast audio on a radio	4
3.0 Earshot Sound Files	5
4.0 Custom Mappings	6
4.1 Add a custom mapping	7
4.2 Define custom fire and detonation overrides	10
4.3 Export custom mappings to spreadsheet	11
5.0 Environmental Sounds	15
6.0 MetaVR™ Terrain Data	17
7.0 VR-Forces Weather	19
7.1 Rain Intensity	19
7.2 Sea State	19
7.3 Wind Speed	21
8.0 Earshot Statistics	22
Appendix A: VoisNet Synchronization	25
A-1 Enable VoisNet Synchronization on the Voisus server	25
A-2 Enable Sync Mode on the AI-Delta	26
A-3 Verify VoisNet Synchronization	28

1.0 Introduction

Earshot creates a virtual auditory environment that distributes sound based on sound sources and listener locations. Built for training in an open area, it allows trainees to move around in their environment and experience a full, realistic sound scape. Earshot is compatible with any training medium, including domes, ship bridge simulators, and serious games.

As shown in the figure below, the entity generator sends Distributed Interactive Simulation (DIS) protocol data units (PDUs) that represent fire, detonation, entity, and environmental sound effects to Earshot running on the Voisus server. Earshot then generates sound by detecting a listener on the network and identifying nearby sounds he or she would hear (e.g. trucks, planes, gunfire in the distance, explosions).

Earshot calculates the source's volume based on its position in the virtual environment. Based on this calculation, it distributes the sound among the speakers, which tells the listener where the sound is coming from. To distribute sound in the 3D environment, Earshot needs to know the number of speakers and their locations. If a new speaker is added to the setup, Earshot automatically adjusts the sound coming out of all speakers to compensate.




Figure 1: Earshot theory of operation

Intended for maintenance technicians and/or users, the *Earshot User Guide* explains how Earshot works and describes how to set up a viewpoint, add sound files, create custom mappings, and complete other configurations. Additionally, this user guide explains how to monitor the system's connectivity on **Earshot Statistics**.

2.0 Viewpoints

Viewpoints is the primary configuration tool for Earshot. On this page, you can create a viewpoint, assign it to a virtual entity, and set up speakers. To add a new viewpoint, follow these steps:

1. From the top-left navigation bar, go to **Earshot** (🔊) > **Viewpoints**.




Figure 2: Viewpoints navigation

2. From the left toolbar, select **Add Viewpoint** (+).
3. In **Name**, enter a new name if desired.
4. Select **DIS Exercise**, and choose an exercise.




Figure 3: Viewpoint Network Settings

5. Under **Location**, assign the viewpoint to a virtual entity using one of the following options:
 - **X, Y, Z**: enter the location of the viewpoint using the geocentric X, Y, and Z coordinates as well as a heading.
 - **Lat, Long, Elevation**: enter the location of the viewpoint using the geodetic latitude, longitude, and elevation coordinates as well as a heading.

- **DIS Entity Location:** examines the DIS network entity state protocol data units (PDUs) for the Site ID, Application ID, and Entity ID. Earshot then uses the location and orientation fields of the PDU.
 - **BSI MACE® Display Lock Location:** refers to a set data PDU that attaches to the MACE display lock entity. Define **Site**, **App**, and **Entity ID**, which range from 0–65,535. Within MACE, on **Visual**, these values must match the **Ownship/Man-in-the-Loop** values.
6. In **Default Audio Volume**, enter a volume percentage.
 7. Under **Public Address**, select **Net**, and choose the net on which you will broadcast. To add or delete nets in the Comm Plan, select **Edit Nets** (🔧). For more information about the Comm Plan, go to "Comm Plan" in the *Voisus Client User Guide*.
 8. Under **Speakers**, add a speaker location for each speaker that will connect to Voisus, including subwoofers. Measure the distance of the speaker from the listener's position.

Speakers

+ ☑ 🔧 🗑 Play Noise ☐ Sequence Noise

Channel Name	Relative X (Forward)	Relative Y (Right)	Relative Z (Down)	Balance	Subwoofer	Lowpass Frequency (Hz)
<input type="checkbox"/> Output 1	N/A	N/A	N/A	Center	<input checked="" type="checkbox"/>	100
<input type="checkbox"/> Output 2	0	0	0	Center	<input type="checkbox"/>	N/A
<input type="checkbox"/> Output 3	0	0	0	Center	<input type="checkbox"/>	N/A
<input type="checkbox"/> Output 4	N/A	N/A	N/A	Center	<input checked="" type="checkbox"/>	100
<input type="checkbox"/> Output 5	0	0	0	Center	<input type="checkbox"/>	N/A

Figure 4: Viewpoint Speakers

9. To balance the speaker output's audio, under **Balance**, choose **Left**, **Right**, or **Center**.
10. To designate the speaker as a subwoofer, select **Subwoofer**.
11. To set the cutoff frequency of a subwoofer channel's lowpass filter, select **Lowpass Frequency (Hz)**, and specify a frequency between 20–300 Hz. The default value is 100 Hz.
12. To test the speaker setup, choose a channel, and select Play Noise. This button plays sound out of all the speakers that are selected with a check mark. To stop the speaker test, select Stop Noise.
13. To test each selected speaker one at a time and then repeat, select **Sequence Noise**. When cleared, all speakers play noise simultaneously.

2.1 Broadcast audio on a radio

Transmit Audio on Radio enables you to broadcast Earshot audio through a Distributed Interactive Simulation (DIS) radio. This functionality captures Earshot audio and mixes it into a mono stream. It then inserts the audio into a DIS radio and transmits it over the network, where the Comms Logger can record it for after-action review.

To broadcast audio on a DIS radio, follow these steps:

1. Configure nets in a Voisus Comm Plan, as described in "Add a net" in the [Voisus Client User Guide](#).
2. Add and configure a subwoofer speaker, as described in Section 2.0, "Viewpoints" on page 2.
3. On **Viewpoints**, under **Transmit Audio on Radio**, select **Radio Net**, and choose a Comm Plan net.





Figure 5: Transmit Audio on Radio

3.0 Earshot Sound Files

To go to the **Earshot Sound Files** page, go to **Earshot** () > **Earshot Sound Files**.




Figure 6: Earshot Sound Files navigation

Use **Earshot Sound Files** to upload and install sound files that Earshot uses for custom mappings and environmental sounds.




Figure 7: Earshot Sound Files

Under **Upload**, select **Browse**, and choose a file. **Installed Sound Files** automatically organizes the files alphabetically.

To preview sounds, under **Installed Sound Files**, select **Preview Sound**.

4.0 Custom Mappings

The **Custom Mappings** page maps DIS entities and events to sound effects within the simulation. Earshot creates these mappings using the **DIS Entity Type**, a combination of seven numbers identifying the entity's unique features (i.e., kind, domain, country, category, sub-category, specific, extra). When Earshot locates an entity or event matching one of these types values, it plays the associated audio.

Available sound effects include **Fire** (e.g., gunfire, missile launches, misfires) and the associated **Detonation** events (e.g., bullet impact, gas bombs, grenades, other explosions). Sound files are managed on the **Earshot Sound Files** page. For more information about Earshot sound files, go to Section 3.0, "Earshot Sound Files" on the previous page.

Entity State allows you to define the sound model for an entity (e.g., Tank Medium, Transport Helicopter). ASTi provides these sound models.

With the exception of missiles, most mappings do not require you to set the ammunition events and entity state at the same time. In the figure below, **DIS Entity Type** is mapped to **61mm Mortar Fire** and **Detonation** sound files, but **Entity State** is blank.

Custom Mappings

+ [Icons] Export

Use a value of -1 to specify a wildcard value. Once a field is set as a wildcard, all subsequent fields must also be wildcards.

Name	DIS Entity Type							Fire			Detonation			Entity State
	Kind	Domain	Country	Category	Subcategory	Specific	Extra	Sound File	Loudness (dBm)	Distance (m)	Sound File	Loudness (dBm)	Distance (m)	
<input type="checkbox"/> A10	0	0	0	0	0	0	0	Select sound...	70	1	Select sound...	70	1	A-10
<input type="checkbox"/> 81mm Mortar	2	9	255	2	8	-1	-1	81mm Mortar	108	3	Select sound...	112	10	Select model...
<input type="checkbox"/> 127mm	2	9	255	2	12	-1	-1	127mm Gun	116	2	Select sound...	70	1	Select model...

Figure 8: Custom Mappings

4.1 Add a custom mapping

To add a custom mapping, follow these steps:

1. From the top-left navigation bar, go to **Earshot** (🔊) > **Custom Mappings**.




Figure 9: Custom Mappings navigation

2. To add a new mapping, under **Custom Mappings**, select the plus sign (+). The mapping appears in the list.
3. In **Name**, enter a descriptive name for the new mapping.
4. Under **DIS Entity Type**, enter the following values:
 - a. *Kind*: kind of entity; ranges from 0–255.
 - b. *Domain*: domain of entity (e.g., air, surface, subsurface, space, etc.); ranges from -1–255.
 - c. *Country*: country to which the design of the entity is attributed; ranges from -1–65,535.
 - d. *Category*: category of entity; ranges from -1–255.
 - e. *Subcategory*: subcategory of entity; ranges from -1–255.
 - f. *Specific*: specific information based on subcategory field; ranges from -1–255.

- g. *Extra*: additional specification for **DIS Entity Type**; ranges from -1–255.

Kind	Domain	Country	Category	Subcategory	Specific	Extra
1	2	255	2	4	-1	-1

Figure 10: DIS Entity Type values

As stated at the top of **Custom Mappings**, a -1 value specifies a "wild card," which means that any value is applicable to that field. Once you set a field to -1, subsequent fields must also be -1, as shown in the figure above. All boxes except for **Kind** accept wild card values. Boxes with invalid numbers are outlined red.

5. (Optional) Under **Fire**, select **Sound File**, and choose a fire event. Asterisks display next to custom sound files:




Figure 11: Custom sound file

To add custom sound files, go to Section 3.0, "Earshot Sound Files" on page 5.

6. **Loudness (dB_{SPL})** and **Distance (m)** measure the intensity of the firing sound at a specified distance from the entity. Loudness is measured using sound pressure level in decibels, while distance is measured in meters.
 - a. In **Loudness (dB_{SPL})**, enter a value ranging from 50 dB–200 dB.
 - b. In **Distance (m)**, enter a minimum value of 1 meter.




Figure 12: Fire sound effect settings

7. (Optional) Under **Detonation**, select **Sound File**, and choose detonation event.
8. **Loudness (dB_{SPL})** and **Distance (m)** measure the intensity of the detonation sound at a specified distance from the entity. Loudness is measured in decibels, while distance is measured in meters.
 - a. In **Loudness (dB_{SPL})**, enter a value ranging from 50 dB–200 dB.
 - b. In **Distance (m)**, enter a minimum value of 1 meter.







Figure 13: Detonation sound effect settings

9. (Optional) Under **Entity State**, select **Sound Model**, and choose a model for the entity state.

4.2 Define custom fire and detonation overrides


On **Custom Mappings**, you can define custom overrides for individual fire warheads or detonation results. To define custom overrides, follow these steps:

1. In **Fire** or **Detonation**, select the star icon (). A blue star () means that overrides currently exist. A pop-up window shows the default settings and any existing overrides:



Warhead	Sound File	Loudness (dB SPL)	Distance (m)
<input type="checkbox"/> Default	Select sound...	70	1
<input type="checkbox"/> 0	Select sound...	70	1
<input type="checkbox"/> 1	81mm Mortar	70	1
<input type="checkbox"/> 2	Select sound...	70	1
<input type="checkbox"/> 3	Select sound...	70	1

Figure 14: Fire Warheads custom settings

2. To add a new override, select the plus sign (.
3. In the first column, enter a new value for the override.
4. To view common warhead or result values, select **View Warhead Values** or **View Result Values**.



Fire Warheads

Warhead field values (standard: IEEE 1278.1)

Value	Description
0000	Other
0010	Cargo (Variable Submunitions)
0020	Fuel/Air Explosive
0030	Glass Blads

[Return to Editing](#)

Detonation Results

Detonation result field values (standard: IEEE 1278.1)

Value	Description
0	Other
1	Entity Impact
2	Entity Proximate Detonation
3	Ground Impact

[Return to Editing](#)

Figure 15: View Warhead/Result Values

5. Next to the new override, select **Sound File**, and choose a sound file.

6. **Loudness (dB_{SPL})** and **Distance (m)** measure the sound's intensity at a specified distance from the entity. Loudness is measured using sound pressure level in decibels, while distance is measured in meters.
 - a. In **Loudness (dB_{SPL})**, enter a value ranging from 50 dB–200 dB.
 - b. In **Distance (m)**, enter a minimum value of 1 meter.
7. When finished, select [Save Changes](#).

4.3 Export custom mappings to spreadsheet

When you're finished creating custom mappings, export your finished work to a spreadsheet in comma-separated values (.csv) format. To export your custom mappings, follow these steps:

1. On **Custom Mappings**, select **Export Custom Mappings** ([Export](#)).

Custom Mappings

Use a value of -1 to specify a wildcard value. Once a field is set as a wildcard, all subsequent fields must also be wildcards.

Name	DIS Entity Type							Sound File	Loudness (dBspl)	Distance (m)	Detonation
	Kind	Domain	Country	Category	Subcategory	Specific	Extra				
<input type="checkbox"/> A10	1	2	255	2	4	-1	-1	<input type="checkbox"/> Select sound...	70	1	<input checked="" type="checkbox"/> Select
<input type="checkbox"/> 81mm Mortar	2	9	255	2	8	-1	-1	<input type="checkbox"/> 81mm Mortar	108	3	<input type="checkbox"/> Select
<input type="checkbox"/> 127mm	2	9	255	2	12	-1	-1	<input type="checkbox"/> 127mm Gun	116	2	<input type="checkbox"/> Select

Figure 16: Export Custom Mappings

A .csv file downloads to your local computer in *scenario_custom_mappings.csv* format, where *scenario* represents your current scenario's name. An on-screen message states, “Successfully generated custom mappings file.”

2. Find the file in your **Downloads** folder, and save it to your computer.

- Open the file in a spreadsheet program such as Microsoft Excel, Open Office Calc, or Google Sheets. The spreadsheet lists each custom mapping component (i.e., **DIS Entity Type**, **Fire**, **Detonation**) and its associated value:

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q
	Name	Kind	Domain	Country	Category	Subcategory	Specific	Extra	Fire Sound File	Fire Loudness	Fire Distance	Fire Warheads	Detonation Sound File	Detonation Loudness	Detonation Distance	Detonation Results	Sound Model
1	A10	0	0	0	0	0	0	0		70		1		70		1	80311c6c306f4b2d810e5f3476f17f0
2	81mm Mortar	2	9	225	2	8	-1	-1	81mm_mortar.wav	108	3	2000, 9500	explosion_small_01.wav	112	10	3, 4	
3	127mm	2	9	225	2	12	-1	-1	127mm_gun.wav	116	2	1630	explosion_large_01.wav	70	1, 25, 4, 5		

Figure 17: Custom Mappings spreadsheet

Column A shows the mapping's name, while Columns B–H show the **DIS Entity Type** settings:

DIS Entity Type

Name

☐ A10

☐ 81mm Mortar

Kind **Domain** **Country** **Category** **Subcategory** **Specific** **Extra**

1 2 255 2 4 -1 -1

2 9 255 2 8 -1 -1

A	B	C	D	E	F	G	H
Name	Kind	Domain	Country	Category	Subcategory	Specific	Extra
Mapping-1	0	0	0	0	0	0	0
Mapping-2	1	2	255	2	4	-1	-1

Figure 18: Name and DIS Entity Type view

Columns **I–K** show **Fire** settings on **Custom Mappings**, while Columns **M–O** show **Detonation** settings:

Fire				Detonation			
Sound File		Loudness (dB _{SPL})	Distance (m)	Sound File		Loudness (dB _{SPL})	Distance (m)
★	Select sound... ▾	70	1	★	Select sound... ▾	70	1
★	81mm Mortar ▾	108	3	☆	Explosion Smal ▾	112	10
☆	127mm Gun ▾	116	2	☆	Explosion Larg ▾	70	1

I	J	K	L	M	N	O
Fire Sound File	Fire Loudness	Fire Distance	Fire Warheads	Detonation Sound File	Detonation Loudness	Detonation Distance
	70	1			70	1
81mm_mortar.wav	108	3	2000, 9500	explosion_small_01.wav	112	10
127mm_gun.wav	116	2	1630	explosion_large_01.wav	70	1

Figure 19: Fire and Detonation view

Columns **L** and **P** show the fire warhead and detonation result overrides in order of appearance:

Fire Warheads				Detonation Results			
Define custom overrides for individual fire warheads.				Define custom overrides for individual detonation results.			
<div>⊕ ⊖ ⌕ ⌵</div>				<div>⊕ ⊖ ⌕ ⌵</div>			
Warhead	Sound File	Loudness (dB _{SPL})	Distance (m)	Result	Sound File	Loudness (dB _{SPL})	Distance (m)
<input type="checkbox"/> Default	81mm Mortar ▾	108	3	<input type="checkbox"/> Default	Explosion Larg ▾	/C	1
<input checked="" type="checkbox"/> 2000	explos_01_bomben-appe v ▾	70	1	<input type="checkbox"/> 1	thud ▾	/C	1
<input checked="" type="checkbox"/> 9500	81mm Mortar ▾	70	1	<input checked="" type="checkbox"/> 25	Cluster 1 explosion ▾	/C	1
<div>View Warhead Values</div>				<div>View Result Values</div>			
<div>Cancel Save Changes</div>				<div>Cancel Save Changes</div>			

L	M	N	O	P
Fire Warheads	Detonation Sound File	Detonation Loudness	Detonation Distance	Detonation Results
		70		
2000, 9500	explosion_small_01.wav	112	10	3, 4
1630	explosion_large_01.wav	70	1	25, 4

Figure 20: Fire Warhead and Detonation Result override view

Column **Q** shows entity state sound model settings:




Figure 21: Entity State Sound Model view

5.0 Environmental Sounds

To go to the **Environmental Sounds** page, go to **Earshot** () > **Environmental Sounds**.




Figure 22: Environmental Sounds navigation

Environmental sounds generate sound in a specific area. An environmental process protocol data unit (PDU) determines the sound's intensity and location. You can insert sounds into the simulation that do not have an associated Distributed Interactive Simulation (DIS) entity (e.g., background noise from a market area, wind noise in an open field). An environmental process PDU also defines the sound's spherical shape and position. Specifically, the system responds to Sphere 1 and Bounding Sphere types.




Figure 23: Earshot concept

To use this element, match the DIS parameters to those of the desired environmental process PDU on the network. Once the system detects the PDU, the audio file in **Sound File** plays.

Select from uploaded sounds in the **Sound File** library. The sound continues to play as long as the environmental process persists on the network.

Example Environmental Sound

Name

Example Environment

DIS Mapping

Kind

0

Domain

0

Country

0

Category

0

Subcategory

0

Specific

0

Extra

0

Sound File

Select sound...

Sound File Volume


1

Figure 24: Environmental Sounds page

Use the **Sound File Volume** control to adjust the level to a desired value ranging from 0–2.0.

6.0 MetaVR™ Terrain Data

MetaVR Terrain Data links the Voisus server to a customer-furnished PC sharing terrain data via Samba network-sharing protocol. To enable MetaVR terrain data access, follow these steps:

1. From the navigation bar at the top of the page, go to **Earshot** () > **MetaVR Terrain Data**.






Figure 25: MetaVR Terrain Data navigation

2. In **Server IP Address**, enter the IP address of the computer hosting MetaVR terrain data.
3. **Directory on Network Share** points the Voisus server to a shared directory folder on the host computer. Enter the directory folder's name.
4. In **Username** and **Password**, enter the login credentials of the computer hosting MetaVR terrain data.
5. When finished, select .


6. Confirm **Status** displays a green check mark (✓):



The screenshot shows the 'MetaVR™ Terrain Data' configuration page. It includes fields for 'Server IP Address', 'Directory on Network Share' (containing 'sample_terrain_tiles'), 'Username', and 'Password'. A blue 'Connect' button is present. At the bottom, the 'Status' is indicated by a green checkmark (✓).

Figure 26: MetaVR Terrain Data page

A red X (✗) indicates that the Voisus server is disconnected from the host computer. If Federal Information Processing Standards (FIPS) mode is enabled, the Voisus server may not be able to authenticate the network share. To manually disable FIPS mode, contact support@asti-usa.com.




The screenshot shows the 'MetaVR™ Terrain Data' configuration page with a yellow warning banner that reads: 'This system has FIPS mode enabled, which may prevent authentication with the network share.' The configuration fields are the same as in Figure 26. The 'Status' at the bottom is indicated by a red X (✗).

Figure 27: FIPS mode warning

7.0 VR-Forces Weather

VR-Forces® Weather allows you to customize weather sounds. Specifically, you can differentiate levels of rain intensity, sea state, and wind speed.

To add sound files to **Earshot Sound Files**, select **Edit Sounds** () at the top of the page. For more information about Earshot sound files, go to Section 3.0, "Earshot Sound Files" on page 5.

7.1 Rain Intensity

To customize rain intensity sound effects, follow these steps:

1. Under **Rain Intensity**, select **Sound File** corresponding with **Light**, **Medium**, or **Heavy**, and choose an effect.
2. In **Gain**, enter a gain value.
3. In **Range (%)**, enter percentage values ranging from 0–100 percent.

Rain Intensity			
	Sound File	Gain	Range (%)
Light	<input type="text" value="None"/>	<input type="text" value="1"/>	<input type="text" value="0"/> - <input type="text" value="30"/> %
Medium	<input type="text" value="None"/>	<input type="text" value="1"/>	<input type="text" value="30"/> - <input type="text" value="70"/> %
Heavy	<input type="text" value="None"/>	<input type="text" value="1"/>	<input type="text" value="70"/> - <input type="text" value="100"/> %

Figure 28: Rain Intensity settings

7.2 Sea State

To customize sea state sound effects, follow these steps:

1. Under **Sea State**, select **Sound File** corresponding with **Low**, **Medium**, or **High**, and choose an effect.
2. In **Gain**, enter a gain value.

3. In **Range (Douglas Sea State)**, enter low, medium, and high values according to the Douglas Sea Scale:

Value	Description
0	Calm (glassy)
1	Calm (rippled)
2	Smooth (wavelets)
3	Slight
4	Moderate
5	Rough
6	Very Rough
7	High
8	Very High
9	Phenomenal

Table 1: Douglas Sea Scale

Sea State

	Sound File	Gain	Range (Douglas Sea Scale)
Low	<div>None</div>	<div>1</div>	<div>0</div> - <div>3</div>
Medium	<div>None</div>	<div>1</div>	<div>3</div> - <div>7</div>
High	<div>None</div>	<div>1</div>	<div>7</div> - <div>9</div>

Figure 29: Sea State settings

7.3 Wind Speed

To customize wind speed sound effects, follow these steps:

1. Under **Wind Speed**, select **Sound File** corresponding with **Low**, **Medium**, or **High**, and choose an effect.
2. In **Gain**, enter a gain value.
3. In **Range (km/h)**, enter wind speed values ranging from 0–118.5 km/h.

Wind Speed

	Sound File	Gain	Range (km/h)
Low	<div>None</div>	<div>1</div>	<div>0</div> - <div>30</div> km/h
Medium	<div>None</div>	<div>1</div>	<div>30</div> - <div>80</div> km/h
High	<div>None</div>	<div>1</div>	<div>80</div> - <div>118.5</div> km/h

Figure 30: Wind Speed settings

8.0 Earshot Statistics

From the top right, go to **Monitor** (👁) > **Earshot**.




Figure 31: Earshot Statistics navigation

As Earshot's main troubleshooting utility, **Earshot Statistics** lists detected viewpoints and virtual entities close enough to hear, showing their status within the simulation.




Figure 32: Earshot Statistics



Note: *Earshot Statistics* only shows features enabled in the license file. Depending on your configuration, some features may not display.

At the top of the page, **Viewpoint** allows you to choose from the available Earshot viewpoints. For more information about viewpoints, go to Section 2.0, "Viewpoints" on page 2.

Viewpoint Status indicates whether the selected viewpoint is linked to its corresponding DIS entity received from the network. Once linked, the X, Y, Z values represent the viewpoint's location.

Simulation Time shows the current time and date within the simulation. If the simulation time is not provided, the display shows “No Simulation Time Detected.”

DIS Rx Counters shows the total received protocol data units (PDUs) categorized by type.

Viewpoint Speaker Locations indicates whether the user-created speaker locations are connected to a corresponding amplifier channel.

Active Entities displays DIS entities received from the network that are currently producing audio. The following information displays in this area:

- **Entity**: shows the virtual entity's ID number and type; the simulation automatically generates the ID, and the type is derived from ASTi's built-in library or **Custom Map-pings**.
- **Range (m)**: shows the relative distance in meters from the viewpoint.
- **Loudness (dB_{SPL})**: shows the entity's volume using sound pressure level in decibels.
- **Terrain Factor**: if enabled, shows the terrain's level of sound obstruction; ranges from 0–1, where 0 represents full sound obstruction, and 1 represents no sound obstruction; works in conjunction with the Earshot terrain server.
- **Forward (m)**: displays the entity's X coordinate distance from the viewpoint.
- **Right (m)**: displays the entity's Y coordinate distance from the viewpoint.
- **Up (m)**: displays the entity's Z coordinate distance from the viewpoint.

Active Environmental Sounds displays actively playing environmental sounds based on Environmental Process PDUs received from the network. For more information about active environmental sounds, go to Section 5.0, "Environmental Sounds" on page 15.

Fire Events and **Detonation Events** show the last 20 sound effects as they occur in real time. Currently playing sounds light up green and show a green speaker (🔊), while delayed sounds display a clock (🕒).

Fire Events		
🕒 = Sound Delayed 🔊 = Sound Playing		
Munition Type	Range (m)	Loudness (dB _{SPL})
🕒 AK47	61.62	86.24
🔊 AK47	61.62	86.24
AK47	61.62	86.24
AK47	61.62	86.24
AK47	61.62	86.24
AK47	61.62	86.24
AK47	61.62	86.24

Figure 33: Fire Events

Munition Type shows the weapon type (e.g., AK-47), including custom weapons created on **Custom Mappings**. **Range (m)** shows how far away the weapon was fired from the listener, while **Loudness (dB_{SPL})** displays the sound's volume using sound pressure level in decibels.

MetaVR Terrain Data Network Status shows the Voibus server's connection status to the computer hosting MetaVR™ simulation software. For more information about MetaVR terrain data, go to Section 6.0, "MetaVR™ Terrain Data" on page 17.

Appendix A: VoisNet Synchronization

VoisNet Synchronization outputs Earshot aural cue audio using an AI-Delta audio distribution device instead of an Ashly Power Amplifier. Each Voisus server requires one AI-Delta. Because an AI-Delta only uses two channels, this configuration is ideal for programs seeking a smaller hardware footprint.

Before starting, you'll need to complete a few setup tasks:

1. Plug in the AI-Delta, and connect it to the Voisus server's network. For more information about the AI-Delta's network configuration, go to the [AI-Delta Technical User Guide](#).
2. Set up the AI-Delta, add it to the Voisus cloud, and give it a channel identifier on **Hardware Devices**. To add and name hardware clients in the Voisus web interface, go to "Manage hardware devices" in the [Voisus Client User Guide](#).
3. Add a viewpoint, as described in Section 2.0, "Viewpoints" on page 2. Make sure the AI-Delta's **Chan A** identifier on **Hardware Devices** matches the corresponding speakers' **Channel Name** on **Viewpoints**.

This chapter discusses how to:

- Enable VoisNet Synchronization on the Voisus server
- Enable Sync Mode on the AI-Delta
- Verify VoisNet Synchronization

A-1 Enable VoisNet Synchronization on the Voisus server

To enable VoisNet synchronization, follow these steps:

1. From the top right, go to **Manage** () > **Features**.




Figure 34: Features navigation

2. On **System Features**, turn **VoisNet Synchronization** .



Figure 35: turn on VoisNet Synchronization

3. To activate changes, select .

A-2 Enable Sync Mode on the AI-Delta

To enable **Sync Mode** on the AI-Delta, follow these steps:

1. Open a web browser on a computer or tablet sharing a network with the Voisus server.
2. In the address bar, enter the Voisus server's IP address.
3. Log into the Voisus server using the following default credentials:

Username	Password
admin	astirules

4. From the top right, go to **Manage** () > **Hardware Devices**.





Figure 36: Hardware Devices navigation





5. Under **AI-Delta assigned to Cloud ID**, where *ID* is the cloud ID, find the new device, and select **Show Options**.
6. To sync the AI-Delta with the Voisus server, under **Device Audio Settings**, select **Sync mode**.

Hardware Devices

ACU2 AI-Bravo AI-Delta AI-S Amplifier Panel RIU

AI-Delta assigned to Cloud vs_0007b8dca54e

Click the  button to remove the selected AI-Delta from this cloud. Click any channel identifier to change its name.

MAC	Chan A	Chan B	Firmware Version	Status	
<input type="checkbox"/> B827EBB7CE38	vbs2-dev-764-PC	vbs2-dev-764-PC-2	v1.6.2	Ready	<div>Hide Options</div> <div>Start FindMe</div>

Channel Settings

Mic Power: ☐

Preamp(dB): 0 or 10 to 65

Sidetone(%): 0 to 100

Gate Threshold(dB): -140 to 0

Preamp Gain (dB):

Sidetone (%):

Enable Gate: ☒

Gate Threshold (dB):

Channel Settings

Mic Power: ☐

Preamp Gain (dB):

Sidetone (%):

Enable Gate: ☒

Gate Threshold (dB):

IPv6 Info

Link-local address: fe80::ba27:ebff:feb7:ce38

IPv4 Settings

Mode: Static

IPv4 Address:

Netmask:

Gateway:

Device Audio Settings

Sync mode: ☒

Buffer size (ms):

Figure 37: Enable Sync mode

7. Select **Save Changes** ().

A-3 Verify VoisNet Synchronization

To verify that the AI-Delta successfully synced with the Voisus server, follow these steps:

1. From the top right, go to **Monitor** (👁️) > **Earshot**.




Figure 38: Earshot Statistics navigation

2. Under **VoisNet Synchronization**, confirm that **✓ Synchronized** appears:

Earshot Statistics

Viewpoint: Viewpoint-1

Viewpoint Status

Linked	X	Y	Z	Volume (%)
Yes	0.00	0.00	0.00	100

Simulation Time

No Simulation Time Detected

DIS Rx Counters

DIS Entity PDUs	0
DIS Fire PDUs	0
DIS SetData PDUs	0
DIS Detonation PDUs	0
DIS Environmental Process PDUs	0

Active Entities

No Active Entities

Active Environmental Sounds

No Active Environmental Sounds

VoisNet Synchronization

✓ Synchronized

Figure 39: Confirm VoisNet Synchronization

If  displays or **VoisNet Synchronization** is missing, check the following:

- VoisNet synchronization is enabled on the Voisus server.
- On **Hardware Devices**, the AI-Delta is connected to the cloud, and **Sync Mode** is enabled.
- On **Viewpoints**, the **Channel Name** of one or more speakers match the AI-Delta's **Chan A** name on **Hardware Devices**.

If you're still unable to synchronize VoisNet, contact ASTi at support@asti-usa.com.